

Passion®



Description

Passion®, AL063 sporty google smoke shade with black frame.

Design of circular arc mirror with motion.

Integrate nose bridge for comfortable support.

The lens is made of polycarbonate(PC),the impact is not easy to break, effective barrier ultraviolet.

Supply to industry,dust-proof,decoration,polishing,laboratory,pharmacy,etc.

Special Instructions

- * Failure to adhere to all instructions and precautionary measures can result in injury.
- * If the user has eye conditions or vision impairment, they must consult with a registered physician prior to use.
- * Any damages to this protective device, may reduce clarity of sight that could result in injury.
- * Following any major detectable defects on the spectacle, the spectacle should be replaced immediately.
- * This spectacle is suitable for use to the lowest marking on the lens (ocular) and frame.

* If the lens becomes damaged the spectacle should be replaced. Although the manufacturer has examined this eyewear under the system for ensuring quality of production by means of monitoring and inspection, it is recommend that all eyewear should be thoroughly inspected before use to ensure no damage is present.

Specifications

Style:	Polycarbonate with side shields and Comfortable nose pad
Lens:	Polycarbonate
Frame:	Polycarbonate.
Weight:	27g
Additional:	Available also in black(AL063)
Function:	Anti-scratch

Packaging, Storage & Obsolescence

Packed as 12 individually wrapped spectacles in a box and 25 boxes per carton (300 spectacles per carton). Store in a cool dry place.



Inspection Frequency and Details

Prior to use the spectacles should be free of any potential contaminants that can affect its intended performance.

The spectacles should be inspected by the user at the end of every use and again prior to each use. Cracked eyewear must be removed from service as they will reduce eye protection and obstruct vision.

Cleaning & Maintenance

Designed as re-usable protective eyewear. After use clean with a mild cleaning liquid, carefully rinse off all traces of the cleaning liquid and dry with a soft cloth and gently wipe with a soft spectacle cleaning material. Do not clean on clothing nor use abrasive cleaners.

Shelf Life

The duration of these spectacles cannot be determined by a timeline as they are intended for normal day to day use. Ensure that proper care and maintenance (inspection and cleaning) is adhered too. Under normal circumstances the spectacle should offer adequate protection for 3 years.

Disposal

All industrial waste should be disposed of correctly according to local regulations and good disposal practice. Safety eyewear should be disposed of considering the hazardous substances they were used for or could be contaminated with. Please consider recycling.

Product details



Frame Details

One-piece smooth frame,anti-impact and anti-scratch



Nose Bridge Details

Integrated nose bridge for comfortable support



Temple Details

Curved temples, fit to the ear, disperse the weight of the glasses, and wear comfortably

129 INDUSTRIAL ROAD AMALGAM JOHANNESBURG SOUTH AFRICA

P.O.BOX 1432 CROWN MINES 2025

www.usafety.co.za